

Panasonic[®]

PROGRAMMABLE CONTROLLER

FP3/FP10S

RTD INPUT UNIT

Technical Manual



Safety Precautions

Observe the following notices to ensure personal safety or to prevent accidents.

To ensure that you use this product correctly, read this User's Manual thoroughly before use.

Make sure that you fully understand the product and information on safe.

This manual uses two safety flags to indicate different levels of danger.

WARNING

If critical situations that could lead to user's death or serious injury is assumed by mishandling of the product.

- Always take precautions to ensure the overall safety of your system, so that the whole system remains safe in the event of failure of this product or other external factor.
- Do not use this product in areas with inflammable gas. It could lead to an explosion.
- Exposing this product to excessive heat or open flames could cause damage to the lithium battery or other electronic parts.

CAUTION

If critical situations that could lead to user's injury or only property damage is assumed by mishandling of the product.

- To prevent abnormal exothermic heat or smoke generation, use this product at the values less than the maximum of the characteristics and performance that are assure in these specifications.
- Do not dismantle or remodel the product. It could lead to abnormal exothermic heat or smoke generation.
- Do not touch the terminal while turning on electricity. It could lead to an electric shock..
- Use the external devices to function the emergency stop and interlock circuit.
- Connect the wires or connectors securely.
The loose connection might cause abnormal exothermic heat or smoke generation
- Do not allow foreign matters such as liquid, flammable materials, metals to go into the inside of the product. It might cause exothermic heat or smoke generation.
- Do not undertake construction (such as connection and disconnection) while the power supply is on.

Copyright / Trademarks

- This manual and its contents are copyrighted.
- You may not copy this manual, in whole or part, without written consent of Matsushita Electric Works, Ltd.
- Windows and Windows NT are registered trademarks of Microsoft Corporation in the United States and/or other countries.
- All other company names and product names are trademarks or registered trademarks of their respective owners.
- Matsushita Electric Works, Ltd. pursues a policy of continuous improvement of the Design and performance of its products, therefore, we reserve the right to change the manual/ product without notice.

Preface

1. R.T.D. Input Unit: AFP3421

This manual explains the R.T.D. input unit with 4-channel input possibility. The unit can convert the data from a Pt.100 or JPt.100 R.T.D. sensor into digital values for processing them in an FP3 or FP10S in the following specifications:

- -100 °C to +200 °C/-148 °F to +392 °F
- -100 °C to +50 °C/-148 °F to +122 °F
- -50 °C to +100 °C/-58 °F to +212 °F
- -20 °C to +80 °C/-4 °F to +176 °F
- +50 °C to +200 °C/+122 °F to +392 °F

Note:

- Be sure to use a Pt.100 or JPt.100 R.T.D. sensor which conforms to DIN standards.

2. Composition of the Manual

The R.T.D. INPUT UNIT Technical Manual is composed of the following chapters:

- 1. FEATURES:

The features and basics about the units are explained.

- 2. SPECIFICATIONS:

The specifications for the R.T.D. input unit are given.

- 3. INSTALLATION AND SETTINGS:

The unit installation, settings and wiring descriptions are given.

- 4. PROGRAMMING FOR R.T.D. INPUT UNITS:

Key knowledge about programming for the R.T.D. input unit is given.

- 5. TROUBLESHOOTING:

Steps to take when an error occurs are given.

- 6. APPENDIX:

Major data and explanations for using the R.T.D. input unit are given for your reference.

CONTENTS

CHAPTER 1: FEATURES

1-1. Features and Functions	2
1-2. Limitations on Configurations	3
1. Limitations on Unit Installation Position	3
2. Limitations on Unit Current Consumption	3
1-3. I/O Allocation and Slot Position	4
1. I/O Allocation	4
2. Slot Position	4

CHAPTER 2: SPECIFICATIONS

2-1. Parts Terminology and Functions	8
2-2. Specifications	10
1. General Specifications	10
2. Performance Specifications	10
3. Data Conversion Characteristics	11
2-3. Shared Memory Specifications	13
2-4. Dimensions	15

CHAPTER 3: INSTALLATION AND SETTINGS

3-1. Installing a R.T.D. Input Unit	18
1. Basic Configurations	18
2. How to Install a R.T.D. Input Unit	19
3. Installation Environment	20
3-2. Settings	22
1. Temperature Range Settings	22
2. Channel Enable Settings	23
3-3. Wiring	24

CHAPTER 4: PROGRAMMING FOR R.T.D. INPUT UNIT

4-1. The Basics of Programming	28
4-2. Reading Normalized Data	32
4-3. Reading Celsius Data	33
4-4. Reading Averaged Value	34
4-5. Setting Offset for Celsius Data	36
4-6. Monitoring Unit's Self-diagnostic Error Flag	37

CHAPTER 5: TROUBLESHOOTING

5-1. Check Points for Troubleshooting	40
5-2. Troubleshooting	41
5-3. Total-check Error Codes	47
5-4. Self-diagnostic Error Codes	48


CHAPTER 6: APPENDIX

6-1. Shared Memory Specifications	54
6-2. Instructions for Accessing Shared Memory	56
6-3. Terminology	68
INDEX	79
RECORD OF CHANGES	81

FEATURES

- 1-1. Features and Functions 2
- 1-2. Limitations on Configurations 3
 - 1. Limitations on Unit Installation Position 3
 - 2. Limitations on Unit Current Consumption 3
- 1-3. I/O Allocation and Slot Position 4
 - 1. I/O Allocation 4
 - 2. Slot Position 4

1-1. Features and Functions



- **R.T.D. input unit for FP3/FP10S**

This unit converts temperature data from a R.T.D. sensor into digital values for processing by an FP3 or FP10S CPU.

- **Supports Pt.100 and JPt.100 type R.T.D.**

Temperature sensors which may be used are 3-wire Pt.100 and JPt.100 R.T.D.

- **Five selections for temperature measurement range**

The following selections are available for the measurement range:

- -100 °C to +200 °C/-148 °F to +392 °F
- -100 °C to +50 °C/-148 °F to +122 °F
- -50 °C to +100 °C/-58 °F to +212 °F
- -20 °C to +80 °C/-4 °F to +176 °F
- +50 °C to +200 °C/+122 °F to +392 °F

- **Two data styles available**

In addition to converting the temperature data in normalized 0 to 4000 form, the unit can also express the data in digital Celsius data. (The Celsius data is expressed up to the 0.1 degree accuracy by multiplying 10 and the Celsius value together.)

- **Offset settings possible for Celsius data**

An offset value can be set to correct the Celsius data when the data given differs from those of other measuring instruments due to measurement error.

- **Averaging function available for regular and Celsius data**

The unit also has function for averaging normalized and Celsius data. This enables an FP3 or FP10S to handle unstable data.

- **Easy-to-use self-diagnostic functions**

The unit can detect the disconnection or the broke of R.T.D. sensor and temperature range abnormality.

- **Shared memory based communication between an FP3/FP10S CPU and a R.T.D. input unit**


Data exchanges between the FP3/FP10S CPU and a R.T.D. input unit can be performed using the shared memory of the unit. By executing the **F150 (READ)/P150 (PREAD)** and **F151 (WRT)/P151 (PWRT)**, CPU can read various digital data, such as normalized, Celsius and their averaging data, its self-diagnostic condition etc. and can write offset enable flags and offset values.

1-2. Limitations on Configurations

1. Limitations on Unit Installation Position


There are no limitations on the installation position when the R.T.D. input unit is used on the basic system (master backplane with a CPU), on the expansion system (expansion backplane) or on a MEWNET-F (remote I/O) slave unit system.

Basic system




Can be installed in any position.

Expansion system



Can be installed in any position.

MEWNET-F slave unit system



Can be used on a MEWNET-F (remote I/O) slave station.

2. Limitations on Unit Current Consumption

There is limitation current consumption when configuring the FP3 and FP10S systems.


The 5 V power for unit operation is supplied from a power supply unit on the backplane and the total power consumption of all installed units must be less than the power supply unit capacity.

The current consumption for R.T.D. input unit is 500 mA at 5 V DC.

Be sure to verify that the capacity of the power supply unit of the backplane is sufficient for controlling units installed.

The internal power supply (5 V) goes to each unit via the backplane bus.

Power supply unit	Rated output current (5 V)
AFP3631	2.4 A
AFP3636	6 A
AFP3634	2.4 A




Note:

- For details about the limitations on the current consumption, refer to "FP3/FP10S HARDWARE Technical Manual."

1-3. I/O Allocation and Slot Position

1. I/O Allocation

- I/O addresses for each unit can be allocated according to the type of units and its location in one of the following two methods:
 - Automatic I/O allocation
- I/O addresses are automatically allocated according to the type of units and its location each time power is supplied to the system.
- With this I/O allocation method, sixteen points (16SX) are occupied for each R.T.D. input unit.
 - Arbitrary I/O allocation
- I/O addresses can be freely allocated using the NPST-GR Software.
- Even with this I/O allocation method, sixteen points (16SX) must be allocated for each R.T.D. input unit in the same way as automatic I/O allocation.




Note:

- For details about the automatic and arbitrary I/O allocation methods, refer to the “FP3/FP10S HARDWARE Technical Manual.”

2. Slot Position

- For programming for the R.T.D. input unit control, the unit position (slot number) is required as:

Program examples




Note:


- If a R.T.D. input unit is installed on a MEWNET-F (remote I/O) slave station, the **F152 (RMRD)/P152 (PRMRD)** and **F153 (RMWT)/P153 (PRMWT)** instructions are used specifying the slot position of the MEWNET-F slave station. For details about the instructions, refer to page 56, “6-2. Instructions for Accessing Shared Memory.”

- Slot numbers are used for expressing the position of units except for the CPU and power supply unit. The slot number is assigned for each unit for the FP3 and FP10S systems, starting from the unit in the slot nearest to the CPU as shown in the following example.

Master Backplane




Expansion Backplane (board number 1)



On five slot backplanes, each of the three open slots, which actually do not exist, is counted as one slot.
On three slot backplanes, each of the five open slots, which actually do not exist, is counted as one slot.


Expansion Backplane (board number 2)



SPECIFICATIONS

- 2-1. Parts Terminology and Functions 8
- 2-2. Specifications 10
 - 1. General Specifications 10
 - 2. Performance Specifications 10
 - 3. Data Conversion Characteristics 11
- 2-3. Shared Memory Specifications 13
- 2-4. Dimensions 15

2-1. Parts Terminology and Functions



① Operation monitor LED

- This LED lights green during normal operation.
- This LED lights red when an error occurs.

② Input terminal

Input wiring section connected to input field devices. This terminal block can be removed by loosening the terminal fixing screws. Terminals marked with “•” cannot be used.

③ Terminal fixing screw

The terminal block can be removed after loosening these screw.

④ Dip switches

These dip switches specifies the effective temperature range, R.T.D. sensor type and effective number of channels as follows:

- Effective temperature range (SW1, SW2 and SW3) and sensor type (SW4) settings

The effective temperature range settings vary depending on which of the two sensor will be used as:

Using Pt.100 sensor (Be sure to set the SW4 to OFF.)

Temperature range setting for type sensor	-100 °C to +200 °C/- 148 °F to +392 °F ON OFF	-100 °C to +50 °C/-148 °F to +122 °F ON OFF	-50 °C to +100 °C/- 58 °F to +212 °F ON OFF	-20 °C to +80 °C/- 4 °F to +176 °F ON OFF	+50 °C to +200 °C/+122 °F to +392 °F ON OFF
SW1					
SW2					
SW3					
SW4					

Using JPt.100 sensor (Be sure to set the SW4 to ON.)

Temperature range setting for type sensor	-100 °C to +200 °C/- 148 °F to +392 °F ON OFF	-100 °C to +50 °C/- 148 °F to +122 °F ON OFF	-50 °C to +100 °C/- 58 °F to +212 °F ON OFF	-20 °C to +80 °C/- 4 °F to +176 °F ON OFF	+50 °C to +200 °C/+122 °F to +392 °F ON OFF
SW1					
SW2					
SW3					
SW4					

- Channel enable (SW5 and SW6) settings

Enabled channels	1 channel enabled (CH0) ON OFF	2 channel enabled (CH0 and CH1) ON OFF	3 channel enabled (CH0 through CH2) ON OFF	4 channel enabled (CH0 through CH3) ON OFF
SW5				
SW6				

Notes:

- The SW5 and SW6 are set to OFF position at factory before shipping. In this setting, all 4 channels are enabled.
- The time required for the sensor data conversion will vary depending on the number of enabled channels.
- For details about the dip switches settings, refer to page 22, “3-2. Settings.”

⑤ **Unit mounting screw**

This screw secures the unit to the backplane.

2-2. Specifications

1. General Specifications


Item	Descriptions
Ambient temperature	0 °C to 55 °C/32 °F to 131 °F
Ambient humidity	30 % to 85 % RH (non-condensing)
Storage temperature	-20 °C to 70 °C/-4 °F to 158 °F
Storage humidity	30 % to 85 % RH (non-condensing)
Vibration resistance	10 Hz to 55 Hz, 1 cycle/min: double amplitude of 0.75 mm/0.030 in., 10 min on 3 axes
Shock resistance	98 m/s ² or more, 4 times on 3 axes
Noise immunity	1,000 Vp-p with pulse width 50 ns or 1 μs (based on in-house measurements)
Operating condition	Free from corrosive gases and excessive dust

2. Performance Specifications

Item	Descriptions
Number of channels	4 channels per unit
Applicable temperature sensor	Pt.100 R.T.D. sensor: -100 °C to +200 °C/-148 °F to 392 °F JPt.100 R.T.D. sensor: -100 °C to +200 °C/-148 °F to 392 °F
Resolution	1/4000
Overall accuracy	1 % of full-scale (0 °C to 55 °C/32 °F to 131 °F) 0.5 % of full-scale (at 25 °C/77 °F)
Conversion speed	Max. 60 ms per channel (*1)
Digital conversion data	Normalized data: K0 to K4000 Celsius data: Temperature up to first decimal place (*2)
Applicable temperature range	-100 °C to +200 °C/-148 °F to +392 °F -100 °C to +50 °C/-148 °F to +122 °F -50 °C to +100 °C/-58 °F to +212 °F -20 °C to +80 °C/-4 °F to +176 °F +50 °C to +200 °C/+122 °F to +392 °F
Insulation	Optical coupler insulation between sensor input terminal and internal circuit No insulation between sensor input channels
Breakdown voltage	500 V AC for 1 min between DC terminal and ground
Insulation resistance	100 MΩ or more, across sensor input terminal and ground (measured with a 500 V DC megger testing)
Internal current consumption (at 5 V DC)	500 mA
Wiring length (*3)	Length of max. 50 Ω wire resistance
Connection method	Terminal block (M 3.5 screw)
Other functions	Averaging function for normalized and Celsius data, Offset adjustment for Celsius data, Self-diagnostic function for sensor connection error and temperature range error, Error indication LED, Internal circuit protection

Notes:


- (*1): The time required for the sensor data conversion will vary between 2-channel and 4-channel types as follows:




- (*2): The Celsius data is expressed up to the 0.1 degree accuracy by multiplying 10 and the Celsius value together.
Example: Temperature measured : 100 °C, Celsius data in the shared memory: K1000
- (*3): For details about the calculation of resistance, refer to page 24, "3-3. Wiring."

3. Data Conversion Characteristics**1) Temperature range settings: -100 °C to +200 °C/-148 °F to +392 °F****■ Input value range vs normalized data conversion characteristics**

Measured temperature (°C)	Normalized data
-100	0
-25	1000
+50	2000
+125	3000
+200	4000

**2) Temperature range settings: -100 °C to +50 °C/-148 °F to +122 °F****■ Input value range vs normalized data conversion characteristics**


Measured temperature (°C)	Normalized data
-100	0
-62.5	1000
-25	2000
+12.5	3000
+50	4000



3) Temperature range settings: -50 °C to +100 °C/-58 °F to +212 °F

■ Input value range vs normalized data conversion characteristics


Measured temperature (°C)	Normalized data
-50	0
-12.5	1000
+25	2000
+62.5	3000
+100	4000



4) Temperature range settings: -20 °C to +80 °C/-4 °F to +176 °F

■ Input value range vs normalized data conversion characteristics


Measured temperature (°C)	Normalized data
-20	0
+5	1000
+30	2000
+55	3000
+80	4000



5) Temperature range settings: +50 °C to +200 °C/+122 °F to +392 °F

■ Input value range vs normalized data conversion characteristics

Measured temperature (°C)	Normalized data
+55	0
+87.5	1000
+125	2000
+162.5	3000
+200	4000



2-3. Shared Memory Specifications

The shared memory is used for communication between the FP3/FP10S CPU and R.T.D. input unit. For accessing the R.T.D. input unit, the CPU should execute **F150 (READ)/P150 (PREAD)** and **F151 (WRT)/P151 (PWRT)** instructions specifying the slot number of the unit and shared memory address.

The shared memory of the R.T.D. input unit is configured as follows:


Shared memory address (word units)	Descriptions																									
K0	Normalized data (Data range: K0 to K4000)	CH0	Temperature measured using the R.T.D. sensor is converted to K0 to K4000 digital data and stored here.																							
K1		CH1																								
K2		CH2																								
K3		CH3																								
K4 to K7	Areas not used.																									
K8	Self-diagnostic error flag area	CH0	If a sensor connection error occurs or the temperature becomes outside the preset temperature range, K1 is set here.																							
K9		CH1																								
K10		CH2																								
K11		CH3																								
K12 to K15	Areas not used.																									
K16	Unit's dip switch settings	The dip switch settings of the unit can be monitored with the lower 6 bits of this word as follows: Example: Pt100, -100 °C to +200 °C (CH0 through CH3 enabled) <table border="1" style="margin-left: 20px;"> <tr> <td>Bit position</td> <td>·</td> <td>4</td> <td>3</td> <td>·</td> <td>·</td> <td>0</td> </tr> <tr> <td>Dip switch numbers</td> <td></td> <td>6</td> <td>5</td> <td>4</td> <td>3</td> <td>2</td> <td>1</td> </tr> <tr> <td>Data</td> <td></td> <td>0</td> <td>0</td> <td>0</td> <td>0</td> <td>0</td> <td>0</td> </tr> </table>		Bit position	·	4	3	·	·	0	Dip switch numbers		6	5	4	3	2	1	Data		0	0	0	0	0	0
Bit position	·	4	3	·	·	0																				
Dip switch numbers		6	5	4	3	2	1																			
Data		0	0	0	0	0	0																			
K17 to K23	Areas not used.																									
K24	Celsius data (Expressed in 0.1 °C units by 10 times the temperature)	CH0	Temperature measured using the R.T.D. sensor is stored in units of 0.1 °C as a number ten times the Celsius value. (e.g.: If the measured temperature is 54.3 °C, K543 will be stored.)																							
K25		CH1																								
K26		CH2																								
K27		CH3																								
K28	Averaged value of Celsius data (Averaged over 5 times)	CH0	Celsius data is averaged over five times and stored.																							
K29		CH1																								
K30		CH2																								
K31		CH3																								
K32 to K39	Areas not used.																									
K40	Averaged value of normalized data (Averaged over 5 times)	CH0	Normalized data is averaged over five times and stored.																							
K41		CH1																								
K42		CH2																								
K43		CH3																								
K44 to K59	Areas not used.																									
K60	Celsius data offset enable flag	Setting 1 here will enable the unit to adjust Celsius data according to the offset value set to addresses K61 to K64.																								

Shared memory address (word units)	Descriptions		
K61	Offset value for Celsius data	CH0	The values in the Celsius and its averaged data areas of the shared memory will be shifted according to offset value set here if 1 is set to address K60. (e.g.: To adjust the Celsius data by 1 °C, set K10 and by -1 °C, set K-10.)
K62		CH1	
K63		CH2	
K64		CH3	

Note:

- When the power is turned ON, all addresses in the shared memory are cleared to 0. Therefore, when you need to backup the shared memory data, be sure to take an appropriate measure using your program such as transferring its contents to the hold-type CPU's registers.

2-4. Dimensions



(Unit: mm/in.)


INSTALLATION AND SETTINGS

- 3-1. Installing a R.T.D. Input Unit 18
 - 1. Basic Configurations 18
 - 2. How to Install a R.T.D. Input Unit 19
 - 3. Installation Environment 20
- 3-2. Settings 22
 - 1. Temperature Range Settings 22
 - 2. Channel Enable Settings 23
- 3-3. Wiring 24

3-1. Installing a R.T.D. Input Unit

1. Basic Configurations


■ Location and restrictions



- The R.T.D. input unit can be installed on any slot position of a CPU equipped master backplane, expansion backplanes or MEWNET-F (remote I/O) slave unit installed master backplanes.
- When building up an FP3/FP10S system, take current consumption into consideration as follows:

Power supply unit	Rated output current (5 V)
AFP3631	2.4 A
AFP3636	6 A
AFP3634	2.4 A

The internal power supply (5 V) goes to each unit via the backplane bus.



■ I/O allocation

- In the automatic I/O allocation, sixteen points of I/Os (16SX) are automatically allocated for each R.T.D. input unit when the power is supplied to the FP3/FP10S system.
- Even with the arbitrary I/O allocation, sixteen points (16SX) must be allocated for each R.T.D. input unit.


Note:

• For details about the I/O allocation, refer to the "FP3/FP10S HARDWARE Technical Manual."


2. How to Install a R.T.D. Input Unit

Before installing the unit, remove the connector cover on the backplane.


1. Fit the unit tabs (two) into the unit holes on the backplane.



2. Push the unit in the direction of the arrow and install onto the backplane.



3. After properly installing the unit to the backplane, secure the mounting screw at the top.




Notes:

- Be sure to turn OFF the power of the FP3/FP10S system before installing units.
- Do not drop the unit or apply excessive force on it.
- Be sure to secure the mounting screw at the top.
- Do not allow parts or other objects to fall into the unit while making wiring connections.
- Leave the dust proofing label on the upper surface of the unit until the wiring is finished.
- Do not touch the connectors on the rear side of the unit. Static electricity may damage the R.T.D. input unit.


3. Installation Environment

■ Installation space


- Leave at least 50 mm/1.969 in. of space between the upper and lower section and the FP3/FP10S system to allow heat to radiate and to facilitate unit replacement.



- When installing devices facing the FP3/FP10S such as on the door of the panel, leave a space of at least 100 mm/3.937 in. between that device and the unit to avoid the effects of heat or radiated noise.



- Although the depth of the unit is 120 mm/4.724 in., leave a space of at least 200 mm/7.874 in. from the mounting surface for tool connections and wiring.



■ Notes on usage

The unit should be used within the following conditions.


- At ambient temperatures of 0 °C to 55 °C/32 °F to 131 °F.
- At ambient humidity of 30 % to 85 % RH.

It should be used in a place where it will not be exposed to:




- Sudden temperature change causing dew condensation.
- Inflammable or corrosive gas.
- Excessive airborne dust or iron particles.
- Benzine, paint thinner, alcohol, other organic solvents or strong alkaline solutions of ammonia or caustic soda.
- Excessive vibration or shock.
- Influence from power transmission lines, high voltage equipment, power cables, power equipment, radio transmitters or any other equipment that generates high switching surges.
- Water splashes.
- Direct sunlight.

■ Notes on installation

- Do not install the programmable controller vertically or horizontally since it may cause abnormal heat generation within the programmable controller above devices which generate large amounts of heat such as heaters, transformers or power resistors.
- Keep the surface of each unit at least 100 mm/3.937 in. away from power lines and electromagnetic switching devices to prevent the influence of noise radiation. In particular, observe this distance when installing control panel doors.
- Install the unit only as shown below.




- Do not install as shown below.



3-2. Settings

Each R.T.D. input unit has 4 sensor input channels. Using six dip switches (SW1 through SW 6) on the rear of the unit, you can set the temperature range, the sensor type and channel enable condition for the R.T.D. input unit. The functions for the dip switches are specified as follows:

Rear of unit



Switch name and setting items

Switch name	Setting items
SW1	Temperature range is decided combined with the sensor type settings of SW4.
SW2	
SW3	
SW4	Sensor type is selected.
SW5	Number of effective channels is specified.
SW6	

1. Temperature Range Settings

Three dip switches (SW1 through SW3) are used for temperature range settings and one dip switch (SW4) is used for sensor type settings. However, as explained above, the effective temperature range settings vary depending on which of the two sensors will be used. Therefore, be sure to confirm the SW4 setting for selecting temperature range.

- When Pt.100 sensor is used:

Be sure to set the SW4 to OFF

Temperature range setting for type sensor	-100 °C to +200 °C / -148 °F to 392 °F ON OFF	-100 °C to +50 °C / -148 °F to +122 °F ON OFF	-50 °C to +100 °C / -58 °F to +212 °F ON OFF	-20 °C to +80 °C / -4 °F to +176 °F ON OFF	+50 °C to +200 °C / +122 °F to +392 °F ON OFF
SW1					
SW2					
SW3					
SW4					

- When JPt.100 sensor is used:
Be sure to set the SW4 to ON

Temperature range setting for type sensor	-100 °C to +200 °C/- 148 °F to 392 °F ON OFF	-100 °C to +50 °C/- 148 °F to +122 °F ON OFF	-50 °C to +100 °C/- 58 °F to +212 °F ON OFF	-20 °C to +80 °C/- 4 °F to +176 °F ON OFF	+50 °C to +200 °C/+122 °F to +392 °F ON OFF
SW1					
SW2					
SW3					
SW4					

2. Channel Enable Settings

Two dip switches (SW5 and SW6) are used for channel enable settings as shown below:


Enabled channels	1 channel enabled (CH0) ON OFF	2 channel enabled (CH0 and CH1) ON OFF	3 channel enabled (CH0 through CH2) ON OFF	4 channel enabled (CH0 through CH3) ON OFF
SW5				
SW6				

Note:


- The SW5 and SW6 are set to OFF position at factory before shipping. In this setting, all 4 channels are enabled.

■ Data conversion time

The time required for the sensor data conversion will vary depending on the number of enabled channels as follows.





3-3. Wiring




■ R.T.D. sensor connection


- Since M3.5 screws are used for terminals, use suitable pressure connection terminals as shown below for a R.T.D. sensor connection.

Terminal style	Specifications	Recommended wire size
Fork terminal	7.2 mm/0.283 in. or less 	0.25 mm ² to 2.63 mm ² A.W.G.33 through A.W.G.13
Round terminal	7.2 mm/0.283 in. or less 	

- Be sure to check the wiring length paying attention to the followings:
 - Use the same type (size/material etc.) for all three wires
 - Adjust the length of wires as resistance of each wire be less than 50 Ω
 - All three wires should have same length




- Be sure to connect the R.T.D. sensor correctly to unit's terminals referring to cable specifications of R.T.D.:



- Keep the R.T.D. sensor's cable away from the load, high-voltage or power wires.
- Never bind the R.T.D. sensor's cable together with the load, high-voltage or power wires.

■ Removable terminal block

- If the terminal fixing screws at both ends are loosened, the terminal block of the R.T.D. input unit can be pulled out from the unit for wiring convenience.
- Never forget to tighten these screws after the wiring completed.



CHAPTER 4

PROGRAMMING FOR R.T.D. INPUT UNIT

4-1. The Basics of Programming	28
4-2. Reading Normalized Data	32
4-3. Reading Celsius Data	33
4-4. Reading Averaged Value	34
4-5. Setting Offset for Celsius Data	36
4-6. Monitoring Unit's Self-diagnostic Error Flag	37

4-1. The Basics of Programming

In order to read data from the R.T.D. input unit, the **F150 (READ)/P150 (PREAD)** instruction is programmed in the CPU. And for offsetting Celsius data, the **F151 (WRT)/P151 (PWRT)** instruction is programmed in the CPU.

In this section, the **F150 (READ)/P150 (PREAD)** and **F151 (WRT)/P151 (PWRT)** instructions are explained using examples:


Note:

- If a R.T.D. input unit is installed on a MEWNET-F (remote I/O) slave station, the **F152 (RMRD)/P152 (PRMRD)** and **F153 (RMWT)/P153 (PRMWT)** instructions should be programmed in the CPU. For details about these instructions, refer to page 62, "**F152 (RMRD)/P152 (PRMRD)**" and page 65, "**F153 (RMWT)/P153 (PRMWT)**"


Program example 1

Condition:

- R.T.D. input unit slot position: Slot 2 position
- Number of enabled channels: 4 channels (CH0 to CH3)
- Type of data read: Normalized data (addresses K0 through K3 of the shared memory)
- CPU registers for storing normalized data: DT10 to DT13




Program




■ Program example 2

Condition:

- R.T.D. input unit slot position: Slot 2 position
- Number of enabled channels: 1 channels (CH0)
- Type of data set: Offset value (address K61 of the shared memory)
Offset enable flag (address K60 of the shared memory)
- CPU register for storing offset value: DT21
- CPU register for storing offset flag: DT20




Program




■ Slot number

Slot numbers are used to express the position of FP3/FP10S units except for the CPU and power supply unit. The slot numbers are assigned for each unit starting from the unit nearest to the CPU and power supply unit. Even if you are using 3- or 5-slot backplane, the open slots, which actually do not exist, is counted as one slot.

Master Backplane




Expansion Backplane (board number 1)



On five slot backplanes, each of the three open slots, which actually do not exist, is counted as one slot.
On three slot backplanes, each of the five open slots, which actually do not exist, is counted as one slot.

Expansion Backplane (board number 2)



■ Shared memory

Values converted from analog to digital are stored in the shared memory of the R.T.D. input unit as follows:

Shared memory address (word units)	Descriptions	
K0	Normalized data (Data range: K0 to K4000)	CH0
K1		CH1
K2		CH2
K3		CH3
K4 to K7	Areas not used.	
K8	Self-diagnostic error flag area	CH0
K9		CH1
K10		CH2
K11		CH3
K12 to K15	Areas not used.	
K16	Unit's dip switch settings	
K17 to K23	Areas not used.	
K24	Celsius data (Expressed in 0.1 °C units by 10 times the temperature)	CH0
K25		CH1
K26		CH2
K27		CH3
K28	Averaged value of Celsius data (Averaged over 5 times)	CH0
K29		CH1
K30		CH2
K31		CH3
K32 to K39	Areas not used.	
K40	Averaged value of normalized data (Averaged over 5 times)	CH0
K41		CH1
K42		CH2
K43		CH3
K44 to K59	Areas not used.	
K60	Celsius data offset enable flag	
K61	Offset value for Celsius data	CH0
K62		CH1
K63		CH2
K64		CH3

Note:

- When the power is turned ON, all addresses in the shared memory are cleared to 0. Therefore, when you need to backup the shared memory data, be sure to take an appropriate measure using your program such as transferring its contents to the hold-type CPU's registers.

4-2. Reading Normalized Data

The temperature data measured by the R.T.D. input unit is automatically converted to the values from K0 to K4000. This data is referred to as “normalized data.” The normalized data for each channel is stored in its shared memory as:

Shared memory address (word units)	Descriptions	
K0	Normalized data (Data range: K0 to K4000)	CH0
K1		CH1
K2		CH2
K3		CH3


Normalized data reading program

The normalized data stored in the shared memory of the R.T.D. unit is read by executing the **F150 (READ)/P150 (PREAD)** instructions as follows.

Condition:

- R.T.D. input unit slot position: Slot 2 position
- Number of enabled channels: 4 channels (CH0 to CH3)
- Type of data read: Normalized data (addresses K0 through K3 of the shared memory)
- CPU registers for storing normalized data: DT10 to DT13


Program example



Normalized data update timing

Normalized data in the shared memory are updated immediately after data conversion processing for the enabled channels. The enabled channels can be set with the dip switches on the rear of the unit. If number of enabled channels will enable the unit to shorten the updating time.

- Normalized data updating time per channel : 60 ms
- Total time required for updating normalized data is calculated using the formula:
60 ms × number of enabled channels



4-3. Reading Celsius Data

The temperature data measured by the R.T.D. input unit is automatically converted to Celsius data. This data is referred to as "Celsius data." Celsius data for each channel is stored in its shared memory as:

Shared memory address (word units)	Descriptions	
K24	Celsius data (Expressed in 0.1 °C units by 10 times the temperature)	CH0
K25		CH1
K26		CH2
K27		CH3


■ Celsius data reading program

Celsius data stored in the shared memory of the R.T.D. input unit is read by executing the **F150 (READ)/P150 (PREAD)** instructions as follows.

Condition:

- R.T.D. input unit slot position: Slot 2 position
- Number of enabled channels: 4 channels (CH0 to CH3)
- Type of data read: Celsius data (addresses K24 through K27 of the shared memory)
- CPU registers for storing normalized data: DT20 to DT23


Program example



■ Celsius data update timing

Celsius data in the shared memory are updated immediately after data conversion processing for the enabled channels. The enabled channels can be set with the dip switches on the rear of the unit. If number of enabled channels will enable the unit to shorten the updating time.

- Celsius data updating time per channel : 60 ms
- Total time required for updating Celsius data is calculated using the formula:
60 ms × number of enabled channels



Shared memory update

Address	
K24	Celsius data for CH0
K25	Celsius data for CH1
K26	Celsius data for CH2
K27	Celsius data for CH3

4-4. Reading Averaged Value

The temperature data measured by the R.T.D. input unit is automatically converted to normalized and Celsius data. These data are averaged over five times inside the R.T.D. input unit and the averaged values for each channel are stored in the shared memory as:

Shared memory address (word units)	Descriptions	
K28	Averaged value of Celsius data (Averaged over 5 times) (Expressed in 0.1 °C units by 10 times the temperature)	CH0
K29		CH1
K30		CH2
K31		CH3
K40	Averaged value of normalized data (Averaged over 5 times)	CH0
K41		CH1
K42		CH2
K43		CH3

■ Averaged value reading program


Celsius data stored in the shared memory of the R.T.D. input unit is read by executing the **F150 (READ)/P150 (PREAD)** instructions as follows.

Condition:

- R.T.D. input unit slot position: Slot 2 position
- Number of enabled channels: 4 channels (CH0 to CH3)


Program example 1

- Type of data read : Averaged value of Celsius data (addresses K28 through K31 of the shared memory)
- CPU registers for storing normalized data: DT30 to DT33



Program example 2


- Type of data read : Averaged value of normalized data (addresses K40 through K43 of the shared memory)
- CPU registers for storing normalized data: DT40 to DT43



■ Averaged value update timing

Averaged value in the shared memory are updated immediately after data conversion processing for the enabled channels. In averaged value, five normalized or Celsius data preceded immediately before update are used. Therefore, until five data can be obtained after starting measurements, correct averaged value cannot be obtained.


- Averaged value updating time per channel : 60 ms
- Total time required for updating averaged value is calculated using the formula:
 $60 \text{ ms} \times \text{number of enabled channels}$



↓ Shared memory update

Address	
K28	Averaged value of Celsius data for CH0
K29	Averaged value of Celsius data for CH1
K30	Averaged value of Celsius data for CH2
K31	Averaged value of Celsius data for CH3
~~~~~	
K40	Averaged value of normalized data for CH0
K41	Averaged value of normalized data for CH1
K42	Averaged value of normalized data for CH2
K43	Averaged value of normalized data for CH3

- For getting first correct averaged value after start of measurement, time is required as follows:  
 $60 \text{ ms} \times \text{number of enabled channels} \times 5$



↓ Correct averaged values obtained in the shared memory

Address	
K28	Averaged value of Celsius data for CH0
K29	Averaged value of Celsius data for CH1
K30	Averaged value of Celsius data for CH2
K31	Averaged value of Celsius data for CH3
~~~~~	
K40	Averaged value of normalized data for CH0
K41	Averaged value of normalized data for CH1
K42	Averaged value of normalized data for CH2
K43	Averaged value of normalized data for CH3

4-5. Setting Offset for Celsius Data

In some cases, measurement error may cause the Celsius data measured by the R.T.D. input unit to differ from data measured by other devices. In order to correct this deviation, offset value setting is available for Celsius data. If offset data is specified, all Celsius data obtained in the shared memory are shifted by offset value including averaged value of Celsius data.

In order to offset Celsius data, set a value to the shared memory and then write K1 into the Celsius data offset enable flag area of shared memory (address K60).

Shared memory address (word units)	Descriptions	
K60	Celsius data offset enable flag	
K61	Offset value for Celsius data (Expressed in 0.1 °C units by 10 times the temperature)	CH0
K62		CH1
K63		CH2
K64		CH3


■ Offset value writing program

Writes an offset value for Celsius data into the shared memory of the R.T.D. input unit is read by executing the **F151 (WRT)/P151 (PWRT)** instructions. Then, set K1 to the Celsius data offset enable flag area of the shared memory to make the offset effective.

Condition:

- R.T.D. input unit slot position: Slot 2 position
- Number of enabled channels: 1 channel (CH0)
- Offset value : 1 °C (for setting offset, K10 should be written)
- CPU register for storing offset value: DT61
- Shared memory offset value area for CH0: K61
- CPU register for storing offset enable flag data: DT60
- Shared memory Celsius data offset enable flag area: K60

Program example



4-6. Monitoring Unit's Self-diagnostic Error Flag

If a sensor connection error occurs or a measured temperature becomes outside the preset temperature range, correct data cannot be handled in a FP3/FP10S. In order to check occurrence of such errors, the R.T.D. input unit has self-diagnostic functions. The result of unit's self-diagnosis is stored in its shared memory as.

Shared memory address (word units)	Descriptions	
K8	Self-diagnostic error flag area (K1 is set when a sensor connection or temperature range error is detected)	CH0
K9		CH1
K10		CH2
K11		CH3

Notes:

- If an abnormality is detected in the R.T.D. sensor connection, data in the shared memory becomes as:
 - Normalized data: K8000
 - Celsius data: K20000
- If a temperature range error occurs, unfixed value is set in the shared memory.


■ Self-diagnostic error flag reading program

Self-diagnostic error flag condition stored in the shared memory is monitored by executing the **F150 (READ)/ P150 (PREAD)** instructions as follows.

Condition:

- R.T.D. input unit slot position: Slot 2 position
- Number of enabled channels: 1 channel (CH0)
- Shared memory self-diagnostic error flag area for CH0: K8
- CPU register for storing error flag condition: DT100

Program example



TROUBLESHOOTING

5-1. Check Points for Troubleshooting	40
5-2. Troubleshooting	41
5-3. Total-check Error Codes	47
5-4. Self-diagnostic Error Codes	48

5-1. Check Points for Troubleshooting

When something goes wrong with the R.T.D. input unit installed FP3/FP10S system or with the converted value, check the FP3/FP10S system using the troubleshooting flowcharts in “5-2. Troubleshooting.”


But, first of all, be sure to check the entire system including peripheral devices, referring to the:

- Observe what is happening.
- Check for error repetition.
- Check the status of indicators.
- Check that power is properly supplied to the FP3/FP10S system.
- Check whether the trouble detected is in the FP3/FP10S system or in other field devices.
- Check whether there is a problem with the program or not.

■ Operation monitor LEDs of the FP3/FP10S CPU

The status of the operation monitor LEDs on the FP3/FP10S CPU vary depending on the condition. When checking the operation status of programmable controllers, be sure to check the operation monitor LEDs while referring to the table below.

FP3 CPU example




LED status							Description	Program execution status	Condition
RUN LED	PROG. LED	TEST LED	BREAK LED	ERROR LED	BATT. LED	ALARM LED			
ON	OFF	OFF	OFF	OFF	Varies	OFF	Operation in the RUN mode	Executing	Normal condition
OFF	ON	Varies	OFF	Varies	Varies	OFF	Operation in the PROG. mode	Not-executing	
Flashes	OFF	Varies	OFF	Varies	Varies	OFF	Forced ON/OFF in the RUN mode	Executing	
OFF	ON	Varies	OFF	Varies	Varies	OFF	Forced ON/OFF in the PROG. mode	Not-executing	
ON	OFF	ON	ON	Varies	Varies	OFF	TEST/RUN (break condition)	Not-executing	
ON	OFF	ON	OFF	Varies	Varies	OFF	TEST/RUN (operating condition)	Executing	
OFF	Varies	Varies	Varies	ON	Varies	OFF	Self-diagnostic error (stops)	Not-executing	Abnormal condition
ON	OFF	OFF	OFF	ON	Varies	OFF	Self-diagnostic error (continues)	Executing	
Varies	Varies	Varies	Varies	Varies	ON	OFF	CPU backup battery error	Executing	
Varies	Varies	Varies	Varies	Varies	Varies	ON	Watchdog timer error	Not-executing	
OFF	Flashes	Varies	OFF	Varies	Varies	OFF	MEWNET-F slave waiting error	Not-executing	

5-2. Troubleshooting


When something goes wrong with the R.T.D. input unit installed FP3/FP10S system, refer to the troubleshooting flowcharts starting from the “■ Main troubleshooting flowchart.”

■ Main troubleshooting flowchart



■ Troubleshooting flowchart when ERROR LED is ON

<Condition: an error is detected by the self-diagnostic function>



From page 42

Probably a self-diagnostic error.
Check the program using the programming tool.

- **Using NPST-GR Software Ver. 3.1**

<If you are using MENU 1 screen type>
Open [NPST MENU] by pressing [Esc], and then select “MONITOR” to skip to the [MONITOR] subwindow. In the [MONITOR] subwindow, select “7. STATUS DISPLAY.”

<If you are using MENU 2 screen type>
Open [ONLINE MONITOR FUNCTION MENU] by pressing [Ctrl] + [F10] together, and then select “P. STATUS DISPLAY.”

At the bottom of the [STATUS DISPLAY] window, you can find the error code in “()”, represented in decimal, and comments in “[]”, as shown on the right.

SLF DIAGN ERR CD (50) [BATTERY ERROR]

Error code Comments


- **Using FP programmer II**

Press the keys on the FP programmer II as shown on the right.
When self-diagnostic error occurs, the screen shown on the right is displayed.

ACLRL (-) OP 1 1 0 ENT READ

OP- 110
FUNCTION ERR E45 ← Error code

Check the FP3 or FP10S referring to page 48, “5-4. Self-diagnostic Error Codes.”

- If the self-diagnostic error code of E45 is found in the CPU-R.T.D. input unit communication program section, go to the “ Troubleshooting flowchart for the R.T.D. input unit.”

Cancel error status and start operation again.

- You can cancel the error status in the following ways:

- Turn the power OFF and then ON.
- Cancel the error status using the NPST-GR Software Ver. 3.1 or the FP programmer II. To perform this function, use “OP 112” of the FP programmer II or [STATUS DISPLAY] of NPST-GR Software Ver. 3.1. (This function is not available with a conventional FP programmer or with NPST-GR Software Ver. 3.0 or earlier.)
- Cancel the error status using the **F148 (ERR)/P148 (PERR)** instruction.

Note:


- The error cancellation function of the programming tool and the **F148 (ERR)/P148 (PERR)** instruction is available for FP3 with a CPU version V.4.4 or later and all FP10S.

■ Troubleshooting flowchart for the R.T.D. input unit

Check the communication program

- Check that the slot number, shared memory address and the other program specifications for the **F150 (READ)/P150 (PREAD)** and **F151 (WRT)/P151 (PWRT)** instructions are correct.

Program examples



Notes:


- For details about the slot number, refer to page 4, “1-3. I/O Allocation and Slot Position.”
- For details about the shared memory configuration of the R.T.D. input unit, refer to page 13, “2-3. Shared Memory Specifications.”

Check if an abnormality is detected in the unit.

- Read the status of unit’s self-diagnostic error flag.

Shared memory address (word units)	Descriptions	
K8	Self-diagnostic error flag area (K1 is set when a sensor connection or temperature range error is detected)	CH0
K9		CH1
K10		CH2
K11		CH3


Program example



Go to next page.

From the previous page.

- If an abnormality is detected (K1 is monitored), check the following items:
 - Check if sensor cable is properly connected to the unit. Refer to page 24, “3-3. Wiring.”
 - Check if the dip switches for sensor and temperature range selection (SW1 through SW4) on the rear side of the unit.
- (1) Turn OFF the power for the FP3/FP10S system.
 - (2) Remove the unit from the backplane by loosening the unit mounting screw.
 - (3) Check the settings.



Using Pt. 100 sensor (Be sure to set the SW4 to OFF.)

Temperature range setting for type sensor	-100 °C to +200 °C/ -148 °F to +392 °F	-100 °C to +50 °C/ -148 °F to +122 °F	-50 °C to +100 °C/ -58 °F to +212 °F	-20 °C to +80 °C/ -4 °F to +176 °F	+50 °C to +200 °C/ +122 °F to +392 °F
	ON OFF	ON OFF	ON OFF	ON OFF	ON OFF
SW1	<input type="checkbox"/> <input checked="" type="checkbox"/>	<input checked="" type="checkbox"/> <input type="checkbox"/>	<input type="checkbox"/> <input checked="" type="checkbox"/>	<input checked="" type="checkbox"/> <input type="checkbox"/>	<input type="checkbox"/> <input checked="" type="checkbox"/>
SW2	<input type="checkbox"/> <input checked="" type="checkbox"/>	<input type="checkbox"/> <input checked="" type="checkbox"/>	<input checked="" type="checkbox"/> <input type="checkbox"/>	<input checked="" type="checkbox"/> <input type="checkbox"/>	<input type="checkbox"/> <input checked="" type="checkbox"/>
SW3	<input type="checkbox"/> <input checked="" type="checkbox"/>	<input type="checkbox"/> <input checked="" type="checkbox"/>	<input type="checkbox"/> <input checked="" type="checkbox"/>	<input type="checkbox"/> <input checked="" type="checkbox"/>	<input checked="" type="checkbox"/> <input type="checkbox"/>
SW4	<input type="checkbox"/> <input checked="" type="checkbox"/>	<input type="checkbox"/> <input checked="" type="checkbox"/>	<input type="checkbox"/> <input checked="" type="checkbox"/>	<input type="checkbox"/> <input checked="" type="checkbox"/>	<input type="checkbox"/> <input checked="" type="checkbox"/>

Using JPt. 100 sensor (Be sure to set the SW4 to ON.)

Temperature range setting for type sensor	-100 °C to +200 °C/ -148 °F to +392 °F	-100 °C to +50 °C/ -148 °F to +122 °F	-50 °C to +100 °C/ -58 °F to +212 °F	-20 °C to +80 °C/ -4 °F to +176 °F	+50 °C to +200 °C/ +122 °F to +392 °F
	ON OFF	ON OFF	ON OFF	ON OFF	ON OFF
SW1	<input type="checkbox"/> <input checked="" type="checkbox"/>	<input checked="" type="checkbox"/> <input type="checkbox"/>	<input type="checkbox"/> <input checked="" type="checkbox"/>	<input checked="" type="checkbox"/> <input type="checkbox"/>	<input type="checkbox"/> <input checked="" type="checkbox"/>
SW2	<input type="checkbox"/> <input checked="" type="checkbox"/>	<input type="checkbox"/> <input checked="" type="checkbox"/>	<input checked="" type="checkbox"/> <input type="checkbox"/>	<input checked="" type="checkbox"/> <input type="checkbox"/>	<input type="checkbox"/> <input checked="" type="checkbox"/>
SW3	<input type="checkbox"/> <input checked="" type="checkbox"/>	<input type="checkbox"/> <input checked="" type="checkbox"/>	<input type="checkbox"/> <input checked="" type="checkbox"/>	<input type="checkbox"/> <input checked="" type="checkbox"/>	<input checked="" type="checkbox"/> <input type="checkbox"/>
SW4	<input checked="" type="checkbox"/> <input type="checkbox"/>	<input checked="" type="checkbox"/> <input type="checkbox"/>	<input checked="" type="checkbox"/> <input type="checkbox"/>	<input checked="" type="checkbox"/> <input type="checkbox"/>	<input checked="" type="checkbox"/> <input type="checkbox"/>


Go to next page.

From the previous page.



Check the channel enable settings of the R.T.D. input unit.

- The channel enable switches on the rear side of the unit.
 - (1) Turn OFF the power for the FP3/FP10S system and the input devices.
 - (2) Remove the unit from the backplane.
 - (3) Check the settings for dip switches referring to the following.



Enabled channels	1 channel enabled (CH0) ON OFF	2 channel enabled (CH0 and CH1) ON OFF	3 channel enabled (CH0 through CH2) ON OFF	4 channel enabled (CH0 through CH3) ON OFF
SW5				
SW6				

5-3. Total-check Error Codes

Error code	Name of error	Description	Steps to take
E1	Syntax error	Instruction is incorrectly programmed.	Set the mode of FP-C/FP3/FP5/FP10S/FP10 to PROG. and input the instruction set correctly, referring to the description for the instruction.
E2	Duplicated output error	Two or more OT and KP instructions are programmed using a relay.	Set the mode of FP-C/FP3/FP5/FP10S/FP10 to PROG. and correct the program so that one relay is not used for two or more OT and KP instructions. This error can be disregarded by changing system register 20 setting to K1 (ENAB).
E3	Not pair error	One of the instructions, which must be paired, is missing (e.g., JP and LBL). The paired instruction sets may have been programmed in the incorrect order (e.g., MC and MCE).	Set the mode of FP-C/FP3/FP5/FP10S/FP10 to PROG. and program the missing instruction sets in the proper order, referring to the description of the instruction.
E4	System register parameter error	The operand for the instruction is outside the range set in the system register.	Set the mode of FP-C/FP3/FP5/FP10S/FP10 to PROG. and check the system register parameter using FP programmer II or NPST-GR software (1. SYSTEM REGISTER in the PLC CONFIGURATION).
E5	Program area error	The instruction has been programmed in the incorrect position (e.g., INT and IRET instructions are programmed at the address before the ED instruction).	Set the mode of FP-C/FP3/FP5/FP10S/FP10 to PROG. and program the instruction in the proper position referring to the description of the instruction.
E6	Compile memory full error	The program stored in the FP10S/FP10 is too large to compile in the program memory.	Set the mode of FP10S/FP10 to PROG. and reduce the total number of steps for the program.
E7	High-level instruction type error	In the program, high-level instructions, which execute in every scan and at the leading edge of the trigger, are programmed to be triggered by one contact [e.g., F0 (MV) and P0 (PMV) are programmed using the same trigger continuously].	Set the mode of FP-C/FP3/FP5/FP10S/FP10 to PROG. and correct the program so that the high-level instructions executed in every scan and only at the leading edge are triggered separately.
E8	Operand error	Incorrect operand has been entered for the instruction.	Set the mode of FP-C/FP3/FP5/FP10S/FP10 to PROG. and program the instruction with the proper operand, referring to the description of the instruction.
E9	No program error	Program may be damaged.	Set the mode of FP10S/FP10 to PROG. and try to send the program again using NPST-GR.

5-4. Self-diagnostic Error Codes

Error code (Hexadecimal)	Name of error	Program execution	Description	Steps to take
E20 (H14)	BPU error	Stops	Probably a hardware abnormality.	Please contact your dealer.
E21 (H15)	RAM error	Stops	Probably an abnormality in the internal RAM.	Please contact your dealer.
E22 (H16)	RAM error			
E26 (H1A)	User ROM checksum error	Stops	Probably an abnormality in the optional ROM.	Re-make user ROM and try operating again.
E27 (H1B)	Intelligent module installation error	Stops	Intelligent modules installed exceed the limitations [e.g., more than 3 standard link modules (such as MEWNET-P/-W C-NET or C.C.U.) are installed on the FP3].	Turn OFF FP-C/FP3/FP5/FP10S/FP10 power and configure intelligent modules referring to the hardware manual or technical sheets for each CPU.
E28 (H1C)	System register error	Stops	Probably an abnormality in the system register.	Set the mode of FP-C/FP3/FP5/FP10S/FP10 to PROG. and initialize system registers.
E29 (H1D)	System bus time out error	Stops	Probably a hardware abnormality.	Please contact your dealer.
E30 (H1E)	Interrupt error	Stops	Probably a hardware abnormality.	Please contact your dealer.
E31 (H1F)	Interrupt error	Stops	Interrupt program was executed even if no interrupt trigger turned ON. Probably a hardware abnormality or an abnormality caused by noise.	Turn OFF FP-C/FP3/FP5/FP10S/FP10 power and check the surrounding noise level.
E32 (H20)	Interrupt error		Interrupt program was executed even when no interrupt trigger was turned ON. Probably a hardware abnormality or an abnormality caused by noise.	Turn OFF FP-C/FP3/FP5/FP10S/FP10 power and check the surrounding noise level.
			Probably an INT program corresponding to the interrupt trigger is missing.	Set the mode of FP-C/FP3/FP5/FP10S/FP10 to PROG. and make an INT program which corresponds to the interrupt trigger.
E33 (H21)	Multi-CPU data unmatch error (CPU2 only)	CPU2 stops	Occurs when a FP3 or FP10S is used as CPU2 for a multi-CPU system.	Please contact your dealer.

Error code (Hexadecimal)	Name of error	Program execution	Description	Steps to take
E34 (H22)	Abnormal module error	Stops	An abnormal module is installed.	Check the contents of special data register: - FP-C/FP3/FP5: DT9036 - FP10S/FP10: DT90036 and locate the abnormal module. Then turn OFF the FP-C/FP3/FP5/FP10S/FP10 and replace the unit with a new one.
E35 (H23)	MEWNET-F slave illegal module error	Stops	A module, which cannot be installed on the slave station of the MEWNET-F link system, is installed on the slave station (e.g., MEWNET-W link unit is installed).	Remove the illegal module from the slave station referring to the hardware manual or technical sheets for each CPU.
E36 (H24)	MEWNET-F slave slot number error	Stops	The number of slots or I/Os used for MEWNET-F exceeds the limitation.	Re-configure the system so that the number of slots and I/Os is within the specified range. Refer to the MEWNET-F (REMOTE I/O) SYSTEM Technical Manual.
E37 (H25)	MEWNET-F I/O mapping error	Stops	I/O overlap or I/O setting that is over the range is detected in the allocated I/O and MEWNET-F I/O map.	Set the mode of FP-C/FP3/FP5/FP10S/FP10 to PROG. and re-configure the I/O map correctly.
E38 (H26)	MEWNET-F slave I/O mapping error	Stops	I/O mapping for MEWNET-F I/O terminal boards, I/O terminal units and I/O link module is not correct.	Set the mode of FP-C/FP3/FP5/FP10S/FP10 to PROG. and re-configure the I/O map for slave stations according to the I/O points of the slave stations.
E39 (H27)	IC card read error	Stops	IC card does not exist or program file in the IC card is damaged or is not found when FP10S/FP10 reads the program from the IC card.	Turn OFF the FP10S/FP10 power and properly insert an IC card with the correct program. Then try to read again.
E40 (H28)	Output module fuse blow error (FP5/FP10)	Selectable (default: stops)	Blown fuse in FP5/FP10 output module is detected.	Check the contents of special data registers: - FP5: DT9002 and DT9003 - FP10: DT90002 and DT90003 and locate the module with the blown fuse. Then replace fuse.
	MEWNET-TR master module error (FP3/FP10S)	Selectable (default: stops)	Erroneous MEWNET-TR master module is detected.	Check the contents of special data registers: - FP3: DT9002 and DT9003 - FP10S: DT90002 and DT90003 and locate the erroneous MEWNET-TR master module. Then check the module referring to the FP3/FP10S MEWNET-TR (Remote I/O) SYSTEM Technical Manual.

Error code (Hexadecimal)	Name of error	Program execution	Description	Steps to take
E41 (H29)	Intelligent module error	Selectable (default: stops) System register 22: - to stop execution, set K0 (STOP) - to continue execution, set K1 (CONT)	An abnormality in an intelligent module.	Check the contents of special data registers: - FP-C/FP3/FP5: DT9006 and DT9007 - FP10S/FP10: DT90006 and DT90007 and locate the abnormal intelligent module. Then check the module referring to its manual.
E42 (H2A)	I/O verify error	Selectable (default: stops) System register 23: - to stop execution, set K0 (STOP) - to continue execution, set K1 (CONT)	I/O wiring condition has changed compared to that at time of power-up.	Check the contents of special data registers: - FP-C/FP3/FP5: DT9010 and DT9011 - FP10S/FP10: DT90010 and DT90011 and locate the erroneous module. Then check the module and correct the wiring.
E43 (H2B)	System watchdog timer error	Selectable (default: stops) System register 24: - to stop execution, set K0 (STOP) - to continue execution, set K1 (CONT) System register 30: Using this register, you can change the value of system watchdog timer in the range of 10 ms to 640 ms.	Scan time required for program execution exceeds the setting of the system watchdog timer.	Check the program and modify it so that FP5/FP10S/FP10 can execute a scan within the specified time.
E45 (H2D)	Operation error	Selectable (default: stops) System register 26: - to stop execution, set K0 (STOP) - to continue execution, set K1 (CONT)	An abnormality was detected when a high-level or basic instruction was executed.	Check the contents of special data registers: - FP-C/FP3/FP5: DT9017 and DT9018 - FP10S/FP10: DT90017 and DT90018 to find the program address where the operation error occurred. Then correct the program referring to the description of the instruction.
E46 (H2E)	MEWNET-F communica- tion error	Selectable (default: stops) System register 27: - to stop execution, set K0 (STOP) - to continue execution, set K1 (CONT)	A communication abnormality was caused by a transmission cable or during the power-down of a slave station.	Check the contents of special data registers: - FP-C/FP3/FP5: DT9131 to DT9137 - FP10S/FP10: DT90131 to DT90137 and locate the abnormal slave station. Then recover the slave condition referring to the MEWNET-F(REMOTE I/O) SYSTEM Technical Manual.

Error code (Hexadecimal)	Name of error	Program execution	Description	Steps to take
E47 (H2F)	MEWNET-F attribute error	Selectable (default: stops)	In the module on the slave station, an abnormality such as: <ul style="list-style-type: none"> - missing module - output unit fuse blow - abnormal intelligent unit was detected. 	Check the contents of special data registers: <ul style="list-style-type: none"> - FP-C/FP3/FP5: DT9131 to DT9137 - FP10S/FP10: DT90131 to DT90137 and locate the abnormal slave station. Then recover the slave condition referring to the MEWNET-F (REMOTE I/O) SYSTEM Technical Manual.
E50 (H32)	Backup battery error	Continues	The voltage of the backup battery lowered or the connector of the backup battery was disconnected.	Check the connection of the backup battery and then replace batteries if necessary.
			System register 4: By setting this system register in K0 (NO), you can disregard this error. If you set to disregard this error: <ul style="list-style-type: none"> - E50 error does not turn ON even if the backup battery of the CPU lowers or is disconnected. (However, the BATT. LED turns ON.) - E54 and E55 errors do not occur even if the battery for the FP10S/FP10 IC card lowers. (For these errors, the BATT. LED does not turn ON.) System register 4 is available for FP-C/ FP3/FP5 with CPU version V.4.4 or later and all FP10S/FP10s.	
E51 (H33)	MEWNET-F terminal station error	Continues	Terminal station settings were not properly performed.	Check stations at both ends of the communication path, and set them in the terminal station using the DIP switches.
E52 (H34)	MEWNET-F I/O update synchronous error	Continues	MEWNET-F system error.	Set the INITIALIZE/TEST selector to the INITIALIZE position while keeping the mode selector in the RUN position. If the same error occurs after this, please contact your dealer.
E53 (H35)	Multi-CPU registration error (CPU2 only)	Continues	Abnormality was detected when the multi-CPU system was used.	Please contact your dealer.

Error code (Hexadecimal)	Name of error	Program execution	Description	Steps to take
E54 (H36)	FP10S/FP10 IC card backup battery error (The BATT. LED does not turn ON for this error.)	Continues	The contents of the IC card cannot be guaranteed since the voltage of the backup battery for the FP10S/FP10 IC card lowered. System register 4: By setting this system register in K0 (NO), you can disregard this error. If you set to disregard this error: - E54 and E55 errors do not occur even if the battery for the FP10S/FP10 IC card lowers. (For these errors, the BATT. LED does not turn ON.) - E50 error does not turn ON even if the backup battery of the CPU lowers or is disconnected. (However, the BATT. LED turns ON.)	Replace the backup battery of the FP10S/FP10 IC card as soon as possible.
E55 (H37)	FP10S/FP10 IC card backup battery error (The BATT. LED does not turn ON for this error.)	Continues	The voltage of the backup battery for FP10S/FP10 IC card lowers. System register 4: By setting this system register in K0 (NO), you can disregard this error. If you set to disregard this error: - E54 and E55 errors do not occur even if the battery for the FP10S/FP10 IC card lowers. (For these errors, the BATT. LED does not turn ON.) - E50 error does not turn ON even if the backup battery of the CPU lowers or is disconnected. (However, the BATT. LED turns ON.)	Replace the backup battery of the FP10S/FP10 IC card.
E100 (H64) to E199 (HC7) E200 (HC8) to E299 (H12B)	Self- diagnostic error set by F148(ERR)/ P148(PERR) instruction	Stops	The self-diagnostic error specified by the F148 (ERR)/P148 (PERR) instruction is transferred to: - FP-C/FP3/FP5: DT9000 - FP10S/FP10: DT90000	Take steps to clear the error condition according to the specification you chose.
		Continues		

6-1. Shared Memory Specifications	54
6-2. Instructions for Accessing Shared Memory	56
6-3. Terminology	68

6-1. Shared Memory Specifications

The shared memory of the R.T.D. input unit is configured as follows:

Shared memory address (word units)	Descriptions																							
K0	Normalized data (Data range: K0 to K4000)	CH0	Temperature measured using the R.T.D. sensor is converted to K0 to K4000 digital data and stored here.																					
K1		CH1																						
K2		CH2																						
K3		CH3																						
K4 to K7	Areas not used.																							
K8	Self-diagnostic error flag area	CH0	If a sensor connection error occurs or the temperature becomes outside the preset temperature range, K1 is set here.																					
K9		CH1																						
K10		CH2																						
K11		CH3																						
K12 to K15	Areas not used.																							
K16	Unit's dip switch settings	<p>The dip switch settings of the unit can be monitored with the lower 6 bits of this word as follows:</p> <p>Example: Pt100, -100 °C to +200 °C (CH0 through CH3 enabled)</p> <table border="1" style="margin-left: auto; margin-right: auto;"> <tr> <td>Bit position</td> <td colspan="6">. 4 3 . . 0</td> </tr> <tr> <td>Dip switch numbers</td> <td colspan="6">6 5 4 3 2 1</td> </tr> <tr> <td>Data</td> <td colspan="6">0 0 0 0 0 0</td> </tr> </table>		Bit position	. 4 3 . . 0						Dip switch numbers	6 5 4 3 2 1						Data	0 0 0 0 0 0					
Bit position	. 4 3 . . 0																							
Dip switch numbers	6 5 4 3 2 1																							
Data	0 0 0 0 0 0																							
K17 to K23	Areas not used.																							
K24	Celsius data (Expressed in 0.1 °C units by 10 times the temperature)	CH0	Temperature measured using the R.T.D. sensor is stored in units of 0.1 °C as a number ten times the Celsius value. (e.g.: If the measured temperature is 54.3 °C, K543 will be stored.)																					
K25		CH1																						
K26		CH2																						
K27		CH3																						
K28	Averaged value of Celsius data (Averaged over 5 times)	CH0	Celsius data is averaged over five times and stored.																					
K29		CH1																						
K30		CH2																						
K31		CH3																						
K32 to K39	Areas not used.																							
K40	Averaged value of normalized data (Averaged over 5 times)	CH0	Normalized data is averaged over five times and stored.																					
K41		CH1																						
K42		CH2																						
K43		CH3																						
K44 to K59	Areas not used.																							
K60	Celsius data offset enable flag	Setting 1 here will enable the unit to adjust Celsius data according to the offset value set to addresses K61 to K64.																						
K61	Offset value for Celsius data	CH0	The values in the Celsius and its averaged data areas of the shared memory will be shifted according to offset value set here if 1 is set to address K60. (e.g.: To adjust the Celsius data by 1 °C, set K10 and by -1 °C, set K-10.)																					
K62		CH1																						
K63		CH2																						
K64		CH3																						

Note:

- When the power is turned ON, all addresses in the shared memory are cleared to 0. Therefore, when you need to backup the shared memory data, be sure to take an appropriate measure using your program such as transferring its contents to the hold-type CPU's registers.

6-2. Instructions for Accessing Shared Memory

For accessing the shared memory installed on the CPU equipped and expansion backplanes, the following instructions are used:

- **F150 (READ)/P150 (PREAD)** instruction for reading data from shared memory 56
- **F151 (WRT)/P151 (PWRT)** instruction for writing data into shared memory 59

For accessing the shared memory installed on a MEWNET-F (remote I/O) slave station, the following instructions are used:

- **F152 (RMRD)/P152 (PRMRD)** instruction for reading data from shared memory 62
- **F153 (RMWT)/P153 (PRMWT)** instruction for writing data into shared memory 65

F150 (READ)

P150 (PREAD)

Data read from intelligent module

Step	Availability
9	All FP-C/FP3/FP5s and FP10S/FP10s
9	

Outline Reads data from the shared memory in an intelligent module.
(P150: executed only when the leading edge of the trigger is detected.)

Program example

Ladder Diagram	Boolean Non-ladder	
	Address	Instruction
	10	ST X 10
	11	F150 (READ)
		H 3
		K 19
		K 4
		DT 0

S1	16-bit equivalent constant for specifying the bank number in the shared memory of the intelligent module.
S2	16-bit equivalent constant for specifying the starting address in the shared memory of the intelligent module (source data address).
n	16-bit equivalent constant for specifying the number of words to be read.
D	Starting 16-bit area address for storing read data (destination data address).


Operands

Operand	Relay				Timer/Counter		Register			Index register		Constant		Index modifier
	WX	WY	WR	WL	SV	EV	DT	LD	FL	IX	IY	K	H	
S1	N/A	N/A	N/A	N/A	N/A	N/A	A	A	A	N/A	N/A	A	A	A
S2	N/A	N/A	N/A	N/A	N/A	N/A	A	A	A	N/A	N/A	A	A	A
n	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	A	A	A
D	N/A	A	A	A	A	A	A	A	A	N/A	N/A	N/A	N/A	A

A: Available
N/A: Not Available

■ Explanation of example

- Reads four words of data stored in the addresses starting from K19 of the intelligent module shared memory (located in slot 3) and stores them in data registers DT0 to DT3 when trigger X10 turns ON.



Description

- This instruction enables a CPU to read data stored in the shared memory of the intelligent module and store them in the specified operand when the trigger turns ON.
- The location and bank number of the intelligent module is specified by S1. The address in the shared memory of the intelligent module is specified by S2 if it does not have banks, and is specified by the combination of S1 and S2 if it does have banks in the shared memory. For details about the shared memory configuration of each intelligent module, refer to the intelligent module manual, and for details about the S1 settings refer to “■ Specifying the module location and bank number S1” in the following section.
- The number of data items read is specified by n, a decimal or hexadecimal constant.

■ Flag conditions

- Error flag (R9007): Turn ON and stays ON when:
 - The area specified using the index modifier exceeds the limit.
 - The area specified using n and D exceeds the limit of the area range.
 The error address is transferred to:
 - FP-C/FP3/FP5: DT9017
 - FP10S/FP10: DT90017
 and held.
- Error flag (R9008): Turns ON for an instant when:
 - The area specified using the index modifier exceeds the limit.
 - The area specified using n and D exceeds the limit of the area range.
 The error address is transferred to:
 - FP-C/FP3/FP5: DT9018
 - FP10S/FP10: DT90018

Note:

- When using special internal relay R9008 as the flag for this instruction, be sure to program it at the address immediately after the instruction.

■ Specifying the module location and bank number S1



The location of the intelligent module and its bank number in the shared memory are specified by the constant S1. Among intelligent modules for FP series programmable controllers, there are ones with and without bank sections in the shared memory. The setting of S1 varies depending on whether you access the module with or without bank sections as follows:

- Accessing the intelligent module with bank section

- Accessing the intelligent module without bank section

S1 = H

S1 = H 0 0




*1 The intelligent modules with bank sections in the shared memory are:

- Data memory units: AFP32091 and AFP32092 for FP3/FP10S
- ET-LAN unit: AFP3790 for FP3/FP10S


*2 Slot numbers are used to express the position of FP-C/FP3/FP5/FP10S/FP10 units except for the CPU and power supply module. The slot numbers are assigned for each module starting from the unit nearest the CPU and power supply module. If you are using an FP-C with the intelligent board function built in, the intelligent board is regarded as the module in slot 7.

- FP3 slot numbering example


Master Backplane



Expansion Backplane (board number 1)



Expansion Backplane (board number 2)



On five slot backplanes, each of the three open slots, which actually do not exist, is counted as one slot.
On three slot backplanes, each of the five open slots, which actually do not exist, is counted as one slot.

F151 (WRT)**P151 (PWRT)**

Data write into intelligent module

Step	Availability
9	All FP-C/FP3/FP5s and FP10S/FP10s
9	

Outline Writes data into the shared memory in an intelligent module.
(P151: Executed only when the leading edge of the trigger is detected.)

Program example

Ladder Diagram	Boolean Non-ladder	
	Address	Instruction
	10	ST X 10
	11	F 151 (WRT)
		H 3
		K 10
		K 5
		DT 0
S1	16-bit equivalent constant for specifying the bank number in the shared memory of the intelligent module.	
S2	Starting 16-bit area address for storing data written in the shared memory.	
n	16-bit equivalent constant for specifying the number of words written in the shared memory.	
D	Starting 16-bit area address for storing data written (destination data address).	


Operands

Operand	Relay				Timer/Counter		Register			Index register		Constant		Index modifier
	WX	WY	WR	WL	SV	EV	DT	LD	FL	IX	IY	K	H	
S1	N/A	N/A	N/A	N/A	N/A	N/A	A	A	A	N/A	N/A	A	A	A
S2	A	A	A	A	A	A	A	A	A	N/A	N/A	N/A	N/A	A
n	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	A	A	A
D	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	A	A	A

A: Available
N/A: Not Available

■ Explanation of example

- Writes five words of data stored in data registers DT10 to DT14 into the intelligent module shared memory (located in slot 3) in the addresses starting from K0.



Description

- This instruction enables a CPU to write data stored in the shared memory of the intelligent module and specified by the combination of S1 and D.
- The location and bank number of the intelligent module is specified by S1. The address in the shared memory of the intelligent module is specified by D if it does not have banks and is specified by the combination of S1 and D if it does have banks in the shared memory. For details about the shared memory configuration of each intelligent module, refer to the applicable intelligent module manual, and for details about the S1 settings refer to “■ Specifying module location and bank number S1” in the following section.
- The number of data items written is specified by n, a decimal or hexadecimal constant.

■ Flag conditions

- Error flag (R9007): Turn ON and stays ON when:
 - The area specified using the index modifier exceeds the limit.
 - The area specified using S2 and n exceeds the limit of the area range.
 The error address is transferred to:
 - FP-C/FP3/FP5: DT9017
 - FP10S/FP10: DT90017
 and held.
- Error flag (R9008): Turns ON for an instant,
 - The area specified using the index modifier exceeds the limit.
 - The area specified using S2 and n exceeds the limit of the area range.
 The error address is transferred to:
 - FP-C/FP3/FP5: DT9018
 - FP10S/FP10: DT90018


Note:

- When using special internal relay R9008 as the flag for this instruction, be sure to program it at the address immediately after the instruction.


■ Specifying the module location and bank number S1

The location of the intelligent unit and its bank number in the shared memory are specified by the constant S1. Among intelligent modules for FP series programmable controllers, there are ones with and without bank sections in the shared memory. The setting of S1 varies depending on whether you access the module with or without bank sections as follows:

- Accessing the intelligent module with bank section



- Accessing the intelligent module without bank section




*1 The intelligent modules with bank sections in the shared memory are:

- Data memory units: AFP32091 and AFP32092 for FP3/FP10S
- ET-LAN unit: AFP3790 for FP3/FP10S


*2 Slot numbers are used to express the position of FP-C/FP3/FP5/FP10S/FP10 units except for the CPU and power supply module. The slot numbers are assigned for each module starting from the module nearest the CPU and power supply module. If you are using an FP-C with the intelligent board function built in, the intelligent board is regarded as the module in slot 7.

- FP3 slot numbering example


Master Backplane



Expansion Backplane (board number 1)



Expansion Backplane (board number 2)



On five slot backplanes, each of the three open slots, which actually do not exist, is counted as one slot.
 On three slot backplanes, each of the five open slots, which actually do not exist, is counted as one slot.

Step	Availability
9	All FP-C/FP3/FP5s and FP10S/FP10s
9	

F152 (RMRD)

P152 (PRMRD)

Data read from MEWNET-F slave station

Outline Reads data from the specified intelligent module of the MEWNET-F slave station
(P152: Executed only when the leading edge of the trigger is detected.)

Program example

Ladder Diagram	Boolean Non-ladder	
	Address	Instruction
	10	ST X 10
	11	F152 (RMRD) DT 0 K 0 K 10 DT 10
S1	Lower 16-bit area of two 16-bit areas for storing control data for F152 (RMRD)/P152 (PRMRD)	
S2	16-bit equivalent constant or 16-bit area for specifying starting shared memory address in the intelligent module	
n	16-bit equivalent constant or 16-bit area for specifying number of readout data items	
D	Starting 16-bit area for storing the read data	


Operands

Operand	Relay				Timer/Counter		Register			Index register		Constant		Index modifier
	WX	WY	WR	WL	SV	EV	DT	LD	FL	IX	IY	K	H	
S1	A	A	A	A	A	A	A	A	A	N/A	N/A	N/A	N/A	A
S2	A	A	A	A	A	A	A	A	A	A	A	A	A	A
n	A	A	A	A	A	A	A	A	A	A	A	A	A	A
D	N/A	A	A	A	A	A	A	A	A	N/A	N/A	N/A	N/A	A

A: Available
N/A: Not Available

■ Explanation of example

- Ten words of data stored at address 0 of the intelligent module specified by DT0 and DT1 are read out and stored in data registers DT10 to DT19 when X10 turns ON.



Description

- This instruction enables a CPU to read data stored in the shared memory of the intelligent module at the MEWNET-F slave station and store it in the specified operand when the trigger turns ON.
- The MEWNET-F master module, slave station number, bank number and slot number are specified by S1 and S1 + 1. The address in the shared memory of the intelligent module is specified by S2. For details about the shared memory configuration of each intelligent module, refer to the intelligent module manual, and for details about the S1 and S1 + 1 settings refer to “■ Specifying the module location and bank number S1 and S1 + 1” in the following section.
- The number of data items read is specified by n.
- The data read out is stored in the area starting from that specified by D.

■ Flag conditions

- Error flag (R9007): Turns ON and stays ON when:
 - The value of S1 and S1 + 1 is incorrect.
 - No MEWNET-F master module is found.
 - The area specified using the index modifier exceeds the limit.
 - The area specified using n and D exceeds the limit of the area range.
 The error address is transferred to:
 - FP-C/FP3/FP5: DT9017
 - FP10S/FP10: DT90017
 and held.
- Error flag (R9008): Turns ON for an instant when:
 - The value of S1 and S1 + 1 is incorrect.
 - No MEWNET-F master module is found.
 - The area specified using the index modifier exceeds the limit.
 - The area specified using n and D exceeds the limit of the area range.
 The error address is transferred to:
 - FP-C/FP3/FP5: DT9018
 - FP10S/FP10: DT90018

- **F152 (RMRD)/P152 (PRMRD), F153 (RMWT)/P153 (PRMWT)** instruction execution flag (R9035): Monitors the execution status of the **F152 (RMRD)/P152 (PRMRD), F153 (RMWT)/P153 (PRMWT)** instructions as follows:
 - 0: One of the **F152 (RMRD)/P152 (PRMRD), F153 (RMWT)/P153 (PRMWT)** instructions is being executed.
 - 1: None of the **F152 (RMRD)/P152 (PRMRD), F153 (RMWT)/P153 (PRMWT)** instructions is being executed.
- **F152 (RMRD)/P152 (PRMRD), F153 (RMWT)/P153 (PRMWT)** instruction end flag (R9036): Checks for errors with the **F152 (RMRD)/P152 (PRMRD), F153 (RMWT)/P153 (PRMWT)** instructions as follows:
 - 0: No error detected while the **F152 (RMRD)/P152 (PRMRD)** or **F153 (RMWT)/P153 (PRMWT)** instruction is being executed.
 - 1: Error detected while the **F152 (RMRD)/P152 (PRMRD)** or **F153 (RMWT)/P153 (PRMWT)** instruction is being executed.
The error code is transferred to:
 - FP-C/FP3/FP5: DT9036
 - FP10S/FP10: DT90036


Notes:

- When using special internal relay R9008 as the flag for this instruction, be sure to program it at the address immediately after the instruction.
- The error codes stored in the DT9036/DT90036 are:
 - H5B: Time-out error (no intelligent module found at the specified location.)
 - H68: No memory error (no memory exists at the specified address.)
 - H71: Send answer time-out error
 - H72: Send buffer full time-out error
 - H73: Response time-out error
 When error H71, H72 or H73 occurs, check system register 32.


■ **Specifying the module location and bank number S1 and S1 + 1**

The location of the intelligent module and its bank number in the shared memory are specified by S1 and S1 + 1. Among intelligent modules for FP series programmable controllers, there are ones with and without bank sections in the shared memory. The setting varies depending on whether you access the module with or without bank section as follows:

- Accessing intelligent module with bank section



- Accessing intelligent module without bank section



Note:

- The intelligent modules with bank sections in the shared memory are:
 - Data memory units: AFP32091 and AFP32092 for FP3/FP10S
 - ET-LAN unit: Not available for MEWNET-F slave station.

F153 (RMWT)**Data write into MEWNET-F
slave station****P153 (PRMWT)**

Step	Availability
9	All FP-C/FP3/FP5s and FP10S/FP10s
9	

Outline Writes data into the specified intelligent module of the MEWNET-F slave station.

(P153: Executed only when the leading edge of the trigger is detected.)

Program example

Ladder Diagram		Boolean Non-ladder	
		Address	Instruction
		10	ST X 10
		11	F153(RMWT)
			DT 0
			DT 250
			K 20 K 500
S1	Lower 16-bit area of two 16-bit areas for storing control data of F153 (RMWT)/P153 (PRMWT)		
S2	Starting 16-bit area for storing data transferred to the shared memory		
n	16-bit equivalent constant or 16-bit area for specifying number of data items written		
D	16-bit equivalent constant or 16-bit area for storing the starting address of the shared memory		


Operands

Operand	Relay				Timer/Counter		Register			Index register		Constant		Index modifier
	WX	WY	WR	WL	SV	EV	DT	LD	FL	IX	IY	K	H	
S1	A	A	A	A	A	A	A	A	A	A	N/A	N/A	N/A	A
S2	A	A	A	A	A	A	A	A	A	A	N/A	N/A	N/A	A
n	A	A	A	A	A	A	A	A	A	A	A	A	A	A
D	A	A	A	A	A	A	A	A	A	A	A	A	A	A

A: Available
N/A: Not Available

■ Explanation of example

- Twenty words of data stored in DT250 to DT269 are written into the shared memory of the intelligent module starting from address 500 when X10 turns ON.



Description

- This instruction enables a CPU to write data stored in the memory areas of the CPU into the shared memory of the intelligent module on the MEWNET-F slave station when the trigger turns ON.
- The MEWNET-F master module, slave station number, bank number and slot number are specified by S1 and S1 + 1. The starting 16-bit area in the CPU, that stores source data, is specified by S2 and the number of words are specified by n. For details about the S1 and S1 + 1 settings refer to “■ Specifying the module location and bank number S1 and S1 + 1” in the following section.
- The number of data items read is specified by n.
- The starting address of the shared memory in the intelligent module is specified by D. For details about the shared memory configuration of each intelligent module, refer to the intelligent module manual.

■ Flag conditions

- Error flag (R9007): Turns ON and stays ON when:
 - The value of S1 and S1 +1 is incorrect.
 - No MEWNET-F master module is found.
 - The area specified using the index modifier exceeds the limit.
 - The area specified using n and D exceeds the limit of the area range.
 The error address is transferred to:
 - FP-C/FP3/FP5: DT9017
 - FP10S/FP10: DT90017
 and held.
- Error flag (R9008): Turns ON for an instant when:
 - The value of S1 and S1 +1 is incorrect.
 - No MEWNET-F master module is found.
 - The area specified using the index modifier exceeds the limit.
 - The area specified using n and D exceeds the limit of the area range.
 The error address is transferred to:
 - FP-C/FP3/FP5: DT9018
 - FP10S/FP10: DT90018

- **F152 (RMRD)/P152 (PRMRD), F153 (RMWT)/P153 (PRMWT)** instruction execution flag (R9035): Monitors the execution status of the **F152 (RMRD)/P152 (PRMRD), F153 (RMWT)/P153 (PRMWT)** instructions as follows:
 - 0: One of the **F152 (RMRD)/P152 (PRMRD), F153 (RMWT)/P153 (PRMWT)** instructions is being executed.
 - 1: None of the **F152 (RMRD)/P152 (PRMRD), F153 (RMWT)/P153 (PRMWT)** instructions is being executed.
- **F152 (RMRD)/P152 (PRMRD), F153 (RMWT)/P153 (PRMWT)** instruction end flag (R9036): Checks for errors with the **F152 (RMRD)/P152 (PRMRD), F153 (RMWT)/P153 (PRMWT)** instructions as follows:
 - 0: No error detected while the **F152 (RMRD)/P152 (PRMRD)** or **F153 (RMWT)/P153 (PRMWT)** instruction is being executed.
 - 1: Error detected while the **F152 (RMRD)/P152 (PRMRD)** or **F153 (RMWT)/P153 (PRMWT)** instruction is being executed.
The error code is transferred to:
 - FP-C/FP3/FP5: DT9036
 - FP10S/FP10: DT90036


Notes:

- When using special internal relay R9008 as the flag for this instruction, be sure to program it at the address immediately after the instruction.
- The error codes stored in the DT9036/DT90036 are:
 - H5B: Time-out error (no intelligent module found at the specified location.)
 - H68: No memory error (no memory exists at the specified address.)
 - H71: Send answer time-out error
 - H72: Send buffer full time-out error
 - H73: Response time-out error
 When error H71, H72 or H73 occurs, check system register 32.


■ Specifying the module location and bank number S1 and S1 + 1

The location of the intelligent module and its bank number in the shared memory are specified by S1 and S1 + 1. Among intelligent modules for FP series programmable controllers, there are ones with and without bank sections in the shared memory. The setting varies depending on whether you access the module with or without bank section as follows:

- Accessing intelligent module with bank section



- Accessing intelligent module without bank section


**Note:**

- The intelligent modules with bank sections in the shared memory are:
 - Data memory units: AFP32091 and AFP32092 for FP3/FP10S
 - ET-LAN unit: Not available for MEWNET-F slave station.

6-3. Terminology

active open:	One of connection opening methods for TCP/IP communication. To establish a virtual connection with another node, an active node must initiate an open call to a passive node.
address:	An alphanumeric value that identifies where data is stored.
ambient temperature:	The temperature of the air surrounding a system.
American Wire Gauge (AWG):	A standard system used for designating the size of electrical conductors. Larger gauge numbers have smaller diameter.
AND:	A Boolean operation that produces a logic “1” output if all inputs are “1”, and a logic “0” if any input is “0.”
ARP:	Abbreviation for Address Resolution Protocol. This is used to transmit the Ethernet (physical) address, which is essential to Ethernet communication, by specifying the IP address. When communicating with a node address, whose Ethernet address is unknown, you only need to specify its IP address if the destination node has the ARP function.
ASCII:	American Standard Code for Information Interchange. ASCII is normally used when alphanumeric (letters and decimal numbers) and control codes are sent as information to printers, etc. ASCII can be represented using 7 or 8 bits and is often expressed in a 2-digit hexadecimal form converted from specific binary expressions. ASCII expressed in 2-digit hexadecimal is called “ASCII HEX code.” For details about actual ASCII codes, refer to the table for ASCII. [EXAMPLE] When a letter “M” is expressed in ASCII code: 7-bit ASCII : 1001101 (binary) ASCII HEX code: 4D (hexadecimal)
asynchronous:	Not synchronous. Repeated operations that take place in patterns unrelated over time.
AWG:	See American Wire Gauge (AWG).
backplane:	A printed circuit board located in the back of a chassis, that contains a data bus, power bus, and mating connectors for units. For FP3, FP5, FP10S and FP10 programmable controllers, two types of backplanes are available: Master Backplane Expansion Backplane
backup:	A device that is kept available to replace something that may fail during operation.
baseband communication:	A communication method which uses digital signals, without modulating them, in a complete bandwidth frequency.
battery backup:	A battery or set of batteries that will provide power to the processor memory only when system power is lost. FP3 CPU, FP10S CPU, and S-RAM type IC cards have a battery backup system.

- battery low:** A condition that exists when the backup battery voltage drops low enough to require battery replacement. For FP3 CPU, FP10S CPU, S-RAM and S-RAM/Flash-EEPROM type IC cards, the ERROR LED turns ON.
- baud:** Formally defined as the shortest pulse width in data communication. However, usually used to refer to the number of binary bits transmitted per second (bps) during serial data communication.
- BCC:** See Block Check Code
- BCD:** See Binary Coded Decimal
- binary:** In general, programmable controllers work with binary numbers in one form or another to represent various codes or quantities. The binary number system uses the number 2 as the base and the only allowable symbols are “0” and “1.” There are no 2s, 3s, etc. Each digit of binary is called as “bit.” “Bit” means “binary digit.” A group of 8 bits is called a “byte” and a group of 16 bits (two bytes) is called a “word.”



The binary number “000000000101011” is expressed in decimal as follows:

$$1 \times 2^0 + 1 \times 2^1 + 0 \times 2^2 + 1 \times 2^3 + 0 \times 2^4 + 1 \times 2^5 + \dots + 0 \times 2^{15}$$


$$= 1 + 2 + 0 + 8 + 0 + 32 + \dots + 0$$

$$= 43$$

Binary Coded Decimal (BCD): One of the codes expressed in binary. BCD is a binary code in which each decimal digit from 0 to 9 is represented by four binary digits (bits). The four positions have a weighted value of 1, 2, 4, and 8, respectively, starting with the least significant bit. A thumbwheel switch is specified as a BCD device, and when connected to a programmable controller, each decimal digit requires four inputs.


BCD is usually expressed grouping four bits as one digit in the same way as the hexadecimal constant H. **When BCD is grouped in four bit units, the BCD is expressed by adding the prefix H to the data. Since the weight of each BCD H code is same as that of decimals, be sure to pay attention not to be confused with hexadecimal numbers when BCD H code is handled.**

Example: When K1993 (decimal) is expressed in BCD.



binary number system:

A number system that uses two symbols, “0” and “1.” Each digit position has a weighted value of 1, 2, 4, 8, 16, 32, 64, and so on beginning with the least significant (right-most) digit.



The sum of N_0 through N_n is the decimal equivalent of the number in base “2.”

Block Check Code (BCC):

This code is used to detect errors in message transmissions. It is created by Exclusive ORing all of the codes from the header through the last text character, then translating the result (8-bit) data into two ASCII characters.

broadband communication:

A communication method which modulates data, such as that for voice and video data transmission, into narrower bands for communication with different users.

buffer:

A group of registers used for temporary data storage. This is used for data transmission and works effectively when there are transmission rate differences between sending and receiving devices.

bug:

Software errors which will cause unexpected actions.

bus:

Power distribution conductors.

Central Processing Unit:

The Central Processing Unit is usually referred to as the CPU. The CPU controls system activities of the programmable controller.

character:

A symbol such as a letter of the alphabet or decimal number. An ASCII character is most commonly used to express characters using binary.

complement:

A logical operation that inverts a signal or bit. The complement of “1” is “0”, and the complement of “0” is “1.”

computer link:

The term “computer link” means the link that functions between a programmable controller and a computer. In the computer link, a computer always initiates communication to a programmable controller and communication is performed using the MEWTOCOL-COM protocol for FP series programmable controllers. To perform computer link communication, you need to prepare a program in the computer that conforms to the MEWTOCOL-COM format. You do not have to make a program for the programmable controller.

connection:

In data communication, a circuit between two data terminals.


CPU:

See Central Processing Unit.

CRT:	Abbreviation for cathode-ray tube.
data transfer:	The data transfer function enables a programmable controller to send or get data to/from another programmable controller. This function is usually used between programmable controllers using the F145 (SEND)/P145 (PSEND) and F146 (RECV)/P146 (PRECV) instructions through the link modules. If you use this for communication with a computer, you need to prepare programs that conform to the MEWTOCOL-DAT format at the computer.
debug:	Removing errors from a program.
decimal number system:	The decimal number system uses the number 10 as the base and the allowable symbols are “0”, “1”, “2”, “3”, “4”, “5”, “6”, “7”, “8”, and “9.” Each digit position has a weighted value of 1, 10, 100, 1000, and so on, beginning with the least significant (right-most) digit.
duplex:	See full-duplex.
EEPROM:	Electrically Erasable Programmable Read Only Memory. EEPROM can be programmed and erased by electrical pulses.
EPROM:	Erasable Programmable Read Only Memory. EPROM can be reprogrammed after being entirely erased with the use of an ultra-violet light source.
FIFO:	See First-In-First-Out.
First-In-First-Out:	The order that data is written in, and read from registers.
flag:	A relay used to detect and remember certain events in the programmable controller. In FP series programmable controllers, some of the special internal relays are used as flags.
full-duplex:	A communication link in which data can be transmitted and received at the same time.
half-duplex:	A communication link in which transmission is limited to one direction at a time.
handshake communication:	Data exchanges between two pieces of devices. For FP series programmable controllers, main signal exchanges between the CPU and the shared memory of intelligent units are referred to as handshake communication.

hexadecimal:

The hexadecimal number system uses 16 as the base. The allowable symbols are numbers 0 through 9 and letters A through F. The letters are substituted for numbers 10 to 15, respectively, to represent all 16 numbers in one digit. The binary number system can easily be represented in hexadecimal with 4 bit groups. In this manner, a very large binary number can be represented by a hexadecimal number with significantly fewer digits.

**hold:**

The memory area whose contents will not be lost or modified if operating power is lost or if the mode of the programmable controller is changed from RUN to PROG.

ICMP:

Abbreviation for Internet Control Message Protocol. This is used to transmit an error message in a network. The FP3/FP10S ET-LAN unit supports the echo reply option to the ping command.

interrupt:

The act of performing a more urgent task by putting off the presently executing task. FP series programmable controllers have three types of interrupts, as follows:

- input initiated interrupt
- high-speed counter initiated interrupt
- time initiated interrupt

I/O:

Abbreviation of Input/Output.

I/O update:

Taking the input data at the input interface into the memory for program execution and outputting the result of program execution to the output interface.

IP:

Abbreviation for Internet Protocol. IP is used to transmit data in datagram units to a destination node specified by an IP address. It provides functions such as the dividing and reassembling of communication data, and communication services between networks via a router.

ladder diagram:

A standard for representing relay-logic systems.

layer:

The conceptual service groups in a network architecture hierarchy. (e.g., transport layer, network layer, data link layer, and physical layer, etc.) In FP series programmable controller networks, the word layer is regarded as a subnetwork which should be accessed via relay stations.

LCD:

Abbreviation for Liquid Crystal Display.

leading edge differential:

A programming technique to operate a bit only for one scan at the moment its input condition turns ON from the OFF state.

Least Significant Bit (LSB): The bit which represents the smallest value in a byte, word, or double-word.

Least Significant Digit (LSD): The digit which represents the smallest value in a number.

LED: Abbreviation for Light-Emitting Diode.


link module: Link modules available for the FP-C/FP3/FP5/FP10S/FP10 are classified into two types: those for the "standard link system" and those for the "high-level link system." Modules for the "standard link system" and "high-level link system" are as follows:

- Modules for the standard link system:
Computer communication modules, C-NET link module, MEWNET-P (Optical) link modules and MEWNET-W (Wire) link modules
- Modules for the high-level link system:
ET-LAN modules and MEWNET-H link modules

link number: Link numbers are used to express the position of link modules separately for the standard and high-level link systems, starting from the link module at the smallest slot position, as follows:


[Link number for standard link system]

- FP-C/FP3/FP5: "S link 1", "S link 2" and "S link 3"
- FP10S/FP10: "S link 1", "S link 2", "S link 3", "S link 4" and "S link 5"



[Link number for high-level link system]

- FP-C: No high-level link modules available for FP-C.
- FP3/FP5/FP10S/FP10: "H link 1", "H link 2" and "H link 3"



malfunction: Incorrect function.

Master Control Relay: A relay which controls any series of programs with its operation. If the master control relay is de-energized, all of the contacts and devices controlled by the master control relay are de-energized.

MEWTOCOL-COM: A communication protocol for FP series programmable controllers that performs communication between a computer and programmable controllers.


modem:	Abbreviation for MODulator/DEModulator. The modem modulates digital signals and transmits them through a telephone line.
Most Significant Bit (MSB):	The bit which represents the greatest value in a byte, word, or double-word.
Most Significant Digit (MSD):	The digit which represents the greatest value in a number.
multidrop link:	A communication link in which one host can communicate with two or more stations.
network:	A group of nodes that use links to exchange information.
node:	A communication station such as computer or programmable controller that is connected to a network.
noise:	Random, unexpected electrical signals, that are caused by radio waves or by electrical or magnetic fields.
non-hold:	The memory area whose contents will be lost or modified if operating power is lost or if the mode of the programmable controller is changed from RUN to PROG.
normally-closed contact:	A contact which is closed when the coil of the relay is not activated.
normally-open contact:	A contact which is open when the coil of the relay is not activated.
offline:	Not being in continuous communication with another processor.
online:	Being in continuous communication with another processor.
overflow:	The act of exceeding the maximum limit in a registers capacity.
parity check:	A check method for the number of 1s in a character when data communication is performed. The parity check is performed by calculating the number of ones in a character.
passive open:	One of connection opening methods for TCP/IP communication. To establish a virtual connection with another node, an active node must initiate an open call to a passive node. When using Ethernet, there are two passive open methods, unpassive and fullpassive.

PC link:	<p>The term “PC link” means one of the link functions between programmable controllers that use specified relays and data registers. In the PC link, you do not have to make a complicated program to enable communication. The PC link function is available separately for the standard link system and high-level link system as follows:</p> <p>[PC link for standard link system]</p> <p>In the standard link system, a maximum of two PC links are available per CPU using MEWNET-P or MEWNET-W link modules. The two PC links for the standard link system are called “PC link S0” and “PC link S1.” For each link communication, 1,024 link relay (L) points and 128 link data register (LD) words are used.</p> <p>The PC link S0 and S1 allocations can be set using system register 46* as follows:</p> <ul style="list-style-type: none"> - When system register 46 is K0, PC link S0 is assigned for the module with the smaller slot number (module with a smaller S link number) of the two. - When system register 46 is K1, PC link S0 is assigned for the module with the larger slot number (module with a larger S link number) of two. <p>* System register 46 is available for any FP-C/FP3/FP5 with CPU version V.4.4. or later and any FP10S/FP10.</p> <p>[PC link for high-level link system]</p> <p>In the high-level link system, a maximum of two PC links are available per CPU using MEWNET-H link modules. The two PC links for the high-level link systems are called “PC link H0” and “PC link H1.” For each link communication, you can assign relays and registers using setting tools.</p> <p>The PC link H0 and H1 allocations are determined by the position of the MEWNET-H link modules. Between the two MEWNET-H link modules used for the PC link, PC link H0 is assigned for the module at the smaller slot number (module with the smaller H link number) of the two, and PC link H1 is assigned for the module at the larger slot number (module with the larger H link number).</p>
peripheral device:	Devices that are connected to the programmable controller.
PLC:	Abbreviation for Programmable Logic Controller. See programmable controller.
potentiometer:	A simple transducer which works based on resistance change.
programmable controller:	A control device which can be programmed to control process or machine operations. A programmable controller is often referred to as a PLC when abbreviated.
RAM:	Random Access Memory. RAM provides an excellent means for easily creating and altering a program. Many of the FP series programmable controllers use RAM with battery backup for the application memory.
register:	A unit of memory for various types of data. A register is usually 16 bits wide.
repeater:	In an Ethernet LAN, a device that re-sends or relays a signal traveling along a LAN cable. It is used to overcome restrictions in segment length in the LAN.
ROM:	Read Only Memory. See EEPROM and EPROM.

route number:

Route numbers are used to express the position of standard and high-level link modules together. The numbers are assigned starting from the link module at the smallest slot position as follows:

- FP-C: "route 1", "route 2" and "route 3" only with 3 standard link modules.
(For FP-C, no high-level link modules are available.)
- FP3/FP5: "route 1", "route 2", "route 3", "route 4", "route 5" and "route 6" including 3 standard and 3 high-level link modules.
- FP10S/FP10: "route 1", "route 2", "route 3", "route 4", "route 5", "route 6", "route 7" and "route 8" including 3 standard and 5 high-level link modules.



RS232C:

An EIA communication standard for data transmission media that is less than 15 m. Most common serial communication standard.

RS422:

An EIA communication standard for data transmission media.

rung:

Term for a ladder program. A rung refers to the programmed instructions that drive one output.

scan:

Time required to read all inputs, execute the program, and update local and remote information.

segment:

In a network, this refers to a piece of coaxial cable that is closed on both ends by a terminator. The segment length is the distance between terminators and varies depending on the type of network.

self-diagnostic function:

A function within the programmable controller which monitors operation and indicates any fault that is detected.

serial communication:



A communication style in which data is transmitted bit by bit serially.

shared memory:


Memory that can be accessed by two or more pieces of devices. In FP series programmable controllers, some intelligent modules have shared memory which can be accessed by both the CPU and the intelligent module.

slot number:

Slot numbers are used for expressing the position of modules except for the CPU and power supply module. The slot numbers are assigned for each module, starting from the module in the slot nearest to the CPU. In the slot numbering system, all types of backplanes are regarded as the 8-slot type and the number is assigned in the order: CPU equipped master backplane, expansion backplane with board number 1, and then the expansion backplane with board number 2, starting from slot number 0.

Master Backplane**Expansion Backplane (board number 1)**

On five slot backplanes, each of the three open slots, which actually do not exist, is counted as one slot. On three slot backplanes, each of the five open slots, which actually do not exist, is counted as one slot.

Expansion Backplane (board number 2)**stop bit:**

The last bit when a character is transmitted.

subnet:

In TCP/IP communication, a part of a network specified by a part of the internet address.

system errors:

Errors resulting from the device or the environment.

system register:

The registers used only for system settings of the programmable controller.

TCP:	Abbreviation for Transmission Control Protocol. This is a connection-based communication method. Since communication services including re-transmission, sequence and flow control for the communication data are provided, this protocol guarantees high communication reliability.
10 BASE 5 network:	One of the CSMA/CD method networks which allows 10 Mbps baseband local area communication with a maximum segment length of 500 m. Usually referred to as Ethernet.
10 BASE T network:	One of the CSMA/CD method networks which allows 10 Mbps baseband local area communication with twisted-pair cable.
10 BASE 2 network:	One of the CSMA/CD method networks which allows 10 Mbps baseband local area communication with a maximum segment length of 200 m. Usually referred to as Cheapernet.
trailing edge differential:	A programming technique to operate a bit only for one scan at the moment its input condition turns OFF from the ON state.
two's complement:	A number system used to express positive and negative numbers in binary. In this system, the number becomes negative if the most significant bit of the data is "1." In FP series programmable controllers, numbers are expressed using the two's complement.
UDP:	Abbreviation for User Datagram Protocol. This is a connectionless communication method. Since no re-transmission, sequence, or flow control for communication data is provided, support at the application level is required to guarantee communication reliability.
underflow:	The act of going below the minimum limit in a register's capacity.
watchdog timer:	A timer that monitors processing time of the programmable controller. If the program does not time out, the processor is assumed to be faulty.
word:	A unit of bits which is usually executed at the same time. A word is composed of 16 bits.

INDEX

A		L	
Averaged Value	34	Limitations on Unit Current Consumption	3
		Limitations on Unit Installation Position	3
		Location and restrictions	18
B		M	
Basic Configurations	18	Main troubleshooting flowchart	41
Basics of Programming	28		
C		N	
Celsius Data	33	Normalized Data	32
Channel Enable Settings	23		
Check Points	40		
D		O	
Data Conversion Characteristics	11	Offset for Celsius Data	36
Dimensions	15	Operation monitor LEDs of the FP3/FP10S CPU	40
F		P	
F150 (READ)	56	P150 (PREAD)	56
F151 (WRT)	59	P151 (PWRT)	59
F152 (RMRD)	62	P152 (PRMRD)	62
F153 (RMWT)	65	P153 (PRMWT)	65
Features	2	Parts Terminology	8
Functions	2, 8	Performance Specifications	10
G		S	
General Specifications	10	Self-diagnostic Error Codes	48
		Self-diagnostic Error Flag	37
		Settings	22
		Shared Memory Specifications	13, 31, 54
		Slot Position	4
		Specifications	10
H			
How to Install a R.T.D. Input Unit	19		
I			
I/O Allocation	4, 18		
Installation Environment	20		
Installing a R.T.D. Input Unit	18		
Instructions	56		

T

Temperature Range Settings	22
Terminology	68
Total-check Error Codes	47
Troubleshooting	41
Troubleshooting flowchart for the R.T.D. input unit	44
Troubleshooting flowchart when ERROR LED is ON	42

W

Wiring	24
--------	----

RECORD OF CHANGES

ACG No.	Date	Description of Changes
ACG-M0071-1	MAR, 1996	First edition

